



**Latest revision of this document: 2014-10-10**

**Listed below changes are official software versions.**

# **Change log NIBE F750**

Version: 6468R2  
Release date: 2014-09-23

## **Changes**

### **Added**

- AHPS-docking SCA41
- ECS 5-8
- Selection "blocking of hot water" in AUX 5.4

### **Changes made in existing functions**

- The room sensor is now calculating average over 15 minutes
- Improved antifreeze function for the heating system
- Calculated flow is calculated in one hour average temperature of the outdoor temperature BT1
- When logging of LOG.SET the variable number is now shown on selected variables that are set to be logged in menu 7.2.1 "Logging"
- Default fuse size is changed to 25A
- When holiday setting is activated and several climate systems, the setting for offset adjustment is shown, if at least one climate system is missing a control indoor room sensor.

### **Menus**

- Menu service info
  - Is showing which address Modbus40 has in menu 3.1
- Russian language has been updated
- Country flags removed in language menu 4.6
- Warning text added and yes/no-choices when you open the forced control menu

### **Accessories**

- Modbus40:
  - If Modbus 40 has a higher version than 7, it will show menu 5.3.11 "modbus" where you can set the wanted address in Modbus 40
  - Will show page for setting of wanted address in Modbus 40 in the start guide if the accessory is activated
  - Supports communication toward lower register parallel with the ordinary. These lower are the same as the "above". Demands version 10 on Modbus40
    - 40004 written in hexadecimal (0x9C44 – 40001 = 3, 0x0003)
- Somewhat lower light intensity in the display