


AWYZ14LBC Capacity/Input data


(1/2)

Heating

<Capacity>



< Input >




*Defrosting operation is performed when temperature is less than 5.5 degrees C.
Frost appears on an outdoor unit heat exchanger at 5.5 or less degrees C.

*Solid line: Integral capacity/Input containing the defrosting cycle.


*Dotted line: Capacity/Input which does not contain the defrosting cycle.

Cooling
< Capacity >

(2/2)



< Input >




*Both capacity and input change largely when temperature is 10 or less degrees C, as outdoor fan speed is decreased due to low ambient temperature cooling control.
*Both capacity and input change more largely at less than 0 degrees C of ambient temperature as outdoor fan speed is decreased further.

AWYZ18LBC Capacity/Input data


(1/2)

Heating

<Capacity>



< Input >




*Defrosting operation is performed when temperature is less than 5.5 degrees C.


Frost appears on an outdoor unit heat exchanger at 5.5 or less degrees C.

*Solid line: Integral capacity/Input containing the defrosting cycle.

*Dotted line: Capacity/Input which does not contain the defrosting cycle.



< Input >



- *Both capacity and input decrease when temperature is 19 or less degrees C, for compressor frequency restrictions operate.
- *Both capacity and input decrease when temperature is 40 or more degrees C, as compressor speed is decreased due to current release protection.
- *Both capacity and input change largely when temperature is 10 or less degrees C, as outdoor fan speed is decreased due to low ambient temperature cooling control.
- *Both capacity and input change more largely at less than 0 degrees C of ambient temperature as outdoor fan speed is decreased further.